



<u>No.</u>	<u>Description</u>	<u>Order Code</u>	<u>Qty</u>	<u>No.</u>	<u>Description</u>	<u>Order Code</u>	<u>Qty</u>
1	Housing	329878	1	20	Ball Bearing	112028	1
2	Screw	329879	1	21	Clamping Nut (L/T)	329897	1
3	Trigger	329880	1	22	Lock Nut	329898	2
4	Air Strainer	329881	1	23	Drive Bushing	329899	1
5	Spring Pin	329882	1	24	Ball Bearing	175441	4
6	Screw	329883	1	25	Wave Washer	329901	1
7	Valve Stem	329884	1	26	O-Ring	329902	1
8	O-Ring	329885	1	27	Exhaust Deflector	329903	2
9	Spring	329886	1	28	Coupling Nut (L/T)	329904	1
10	O-Ring	329887	1	29	Front Casing (L/T)	329905	1
11	Reverse Valve	329888	1	30	Anvil	329906	1
12	Ball Bearing	112054	1	31	Lock Nut	329907	1
13	Rear Plate	329889	1	32	Adaptor	329908	1
14	Spring Pin	329890	2	33	Collet Body	329909	1
15	Cylinder	329891	1	34	Collet Insert 1/4"	304905	1
16	Rotor	329892	1		Collet Insert 3/8"	304903	
17	Blade	329893	4	35	Lock Nut	329911	1
18	Front Plate	329894	1	36	Wrench (14 mm)	280777	1
19	Washer	329895	1	37	Wrench (19 mm)	232161	1